extra Wallpaper Adhesive Super Economy Pack

Technical information sheet

500g / Item no.002501000 / EAN 4007955025016
1kg / Item no.002502000 / EAN 4007955025023



This wallpaper paste is ideal for woodchip, vinyl, textile and embossed wallpapers as well as for all heavy wallpaper types. It offers high initial adhesion and reliable adhesion, especially on rough plaster surfaces. The stable formula enables clean application and ensures a permanently secure hold, even for demanding wallpapering work.

- Reinforced with synthetic resin
- High filling power
- ready for use in approx. 30 minutes

Area of application

Special paste for bonding woodchip, textured, vinyl and embossed wallpapers to plaster, concrete, emulsion paint coatings, plasterboard, etc.

Preparation

The substrate must be dry, smooth, clean, sound and free of separating agents (e.g. dust or grease). Remove all wallpaper residue, poorly adhering paint and distemper. Repair holes and unevenness with filler. Pre-treat sanding and chalking substrates with deep penetrating primer. Pre-paste highly absorbent substrates or prime with deep penetrating primer. Pre-coat rough plasters with a primer.

Processing

Pour the entire contents of the pack into cold water (see table), stirring vigorously, and continue stirring for a short time. Leave the mixture to stand for approx. 30 minutes and stir again vigorously. Paste the cut lengths of wallpaper, lay them together and, after sufficient soaking time, glue them together. For slightly absorbent substrates and to increase moisture resistance, stir a 750 g can of wallcovering adhesive (2 cans of 750 g each for a 1 kg pack of extra special paste) into the prepared special paste. The wallpaper manufacturer's processing instructions must be observed. Do not process below +5 °C air and substrate temperature. Clean tools with water after use. Mixing ratio 500 g packet: Pre-pasting: Mix 1:20 = 10 litres of water = approx. 70 m² Light wallpapers: Mix 1:16 = 8 litres of water = 40-45 m² Rough wallpaper: Mix 1:14 = 7 litres of water = 35-40 m² Textured, vinyl and embossed wallpapers, heavy wallpapers: Mix 1:12 = 6 litres of water = 30-35 m² Mixing ratio 1 kg packet: Pre-pasting: Mix 1:20 = 20 litres of water = approx. 140 m² light wallpapers: 1:16 = 16 litres of water = 80-85 m² woodchip wallpaper: 1:14 = 14 litres of water = 70-75 m² textured, vinyl and embossed wallpapers, heavy wallpapers: 1:12 = 12 litres of water = 60-65 m²

Storage

Store in a cool and dry place!

Baufan Bauchemie Leipzig GmbH ■ Ludwig-Hupfeld-Straße 19 ■ 04178 Leipzig ■ Telephone +49 (0)341 44655-0 ■ Email info@baufan.de ■ www.baufan.com

Note:
All details and data presented in this information sheet are based on our practical experience and laboratory investigations, and reflect the current state of the art. They can, however, only serve as general guidance and shall provide no guarantee of specific properties or performance. Given that the conditions for storage, transportation and application of products are beyond our control, no legal liability may be construed from the information presented here. It shall be the responsibility of the user to check the product's suitability for the envisaged purpose under the specific site or project conditions.