

- extra-high bond strength
- very high moisture resistance when overcoating
- dries to transparent finish
- solvent- and plasticizer-free

Glassfibre and renovation fabrics adhesive

Use

For reliable and durable bonding of glassfibre fabrics, non-woven lining paper and heavy wall coverings (e.g. made from vinyl or textiles) as well as woodchip wallpapers indoors.

Constituents

Comprising: methyl cellulose, starch ether, polyvinyl acetate powder, preservatives and additives

Bulk density: 0.45 g/cm³

pH value: approx. 8

Consumption: approx. 200 g/m²

Substrate preparation

Substrate shall be dry, strong, level, uniformly absorbent, and free from dust and grease. Remove existing wallpaper and badly adhering coatings. Repair cracks, holes and irregularities with baufan® Indoor Filler. Pretreat highly absorbent, friable and chalking substrates and sanded surfaces with baufan® Deeply Penetrating Primer – solvent-free.

Mixing ratio

Stirring vigorously, briskly sprinkle pack contents into cold water (see table) and continue to stir for a short time. Restir prepared mix vigorously after approx. 15 minutes.

	Mixing ratio	Water quantity per pack	Pack suffices for
Pre-pasting	1 : 20	10 ltr	approx. 70 m ²
Woodchip	1: 11	5.5 ltr	approx. 30 m ²
Renovation and reinforcing non-wovens, embossed non-wovens, non-woven woodchip wallpapers, textile wallpapers, heavy wall coverings	1 : 10	5 ltr	approx. 25 m ²
Glass fabrics	1 : 8	4 ltr	approx. 22.5 m ²

Application

Apply adhesive uniformly to substrate over strip width with short-pile roller or brush. Place cut-to-size wallpaper strip into freshly placed adhesive and press down evenly to remove entrapped air. Observance of wallpaper and wall covering manufacturer's application specifications is essential. If so instructed by manufacturer, apply adhesive directly to wall covering and observe prescribed soaking time before bonding. Do not overcoat wall coverings with emulsion paint until adhesive has fully dried.

Note

Do not use at temperatures below +5 °C. Immediately remove adhesive residue with water. Wash tools with water immediately after use.

Storage

Store in cool, dry place, out of reach of children.

Disposal

Dried material residue may be disposed of as domestic or construction site waste. EWC waste code: 08 04 14.

Item No.

102619 500 g Folding box

Note:

All details and data presented in this information sheet are based on our practical experience and laboratory investigations, and reflect the current state of the art. They can, however, only serve as general guidance and shall provide no guarantee of specific properties or performance. Given that the conditions for storage, transportation and application of products are beyond our control, no legal liability may be construed from the information presented here. It shall be the responsibility of the user to check the product's suitability for the envisaged purpose under the specific site or project conditions.