

baufan®

Universal Paint Stripper

Technical information sheet

750ml / Item no.101605 / EAN 4016215101605
5l / Item no.015405001 / EAN 4007955154259



Extra strong universal paint stripper for effortless removal of old paints, varnishes and glazes. The powerful formula has a mild odour, also adheres to vertical surfaces and even removes several layers of paint in just one operation. Easy to apply and effective to use - ideal for interior and exterior renovation and refurbishment work. Ensures clean, well-prepared surfaces for further treatment.

- For removing old paints, varnishes and glazes
- Extra strong
- Mild odour
- Dissolves several layers in one operation

Area of application

Universal paint stripper for removing oil, synthetic resin and emulsion paints. Also cleans rock-hard brushes with natural bristles reliably and thoroughly. Top.

Preparation

Wood, metal and masonry substrates are not attacked, plastics and non-solvent-resistant substrates may be attacked. Free from dichloromethane and N-methylpyrrolidone.

Processing

Protect neighbouring surfaces or surfaces not to be stripped from splashes by covering them with a film! Apply baufan Universal Paint Stripper generously with a brush and allow to take effect. If the paint is difficult to remove, remove the dissolved layer with a spatula and repeat the process. Then rinse the surface with water or thinner.

Consumption

approx. 300 - 600 ml/m²

Storage

Keep container tightly closed in a cool but frost-free place. If unopened and stored properly, shelf life is at least 24 months from date of manufacture (see batch label).

Notes

Processing temperature: +5 °C to +30 °C for material, ambient air and substrate. Avoid inhalation of vapour. Wear protective gloves/eye protection. Repeated contact may lead to chapped or cracked skin. IF ON SKIN (or hair): Remove all contaminated clothing immediately. Wash/shower skin with water. IF INHALED: Remove to fresh air and keep at rest in a position comfortable for breathing. IF IN EYES: Rinse cautiously with water for several minutes. Remove any contact lenses if possible. Continue rinsing. If medical advice is required, have packaging or identification label ready. Dispose of contents/container to hazardous or special waste collection point in accordance with local/regional/national/international regulations.

Note:

All details and data presented in this information sheet are based on our practical experience and laboratory investigations, and reflect the current state of the art. They can, however, only serve as general guidance and shall provide no guarantee of specific properties or performance. Given that the conditions for storage, transportation and application of products are beyond our control, no legal liability may be construed from the information presented here. It shall be the responsibility of the user to check the product's suitability for the envisaged purpose under the specific site or project conditions.